



## **OLHAUSEN GAMES SHUFFLEBOARD CARE AND MAINTENANCE INSTRUCTIONS**

*Before waxing your playfield for the first time, your playfield should be cleaned with Olhausen Games Cleaner Polish. For best results follow all instructions.*

1. Apply Olhausen Games Cleaner Polish with a towel to remove foreign matter from your playing surface. This is the first step in the polishing process. Before the surface dries, buff lightly using a dry towel. OG Cleaner Polish should be used 2 to 3 times a month depending on usage.
2. Olhausen Games Liquid Wax should also be applied with a towel. Repeat the instructions above, buffing lightly with a dry towel until the surface is as smooth as ice. Once again, depending on usage, 2 to 3 times per month is recommended.

DO NOT attempt to improve on these instructions by allowing wax to dry or by using buffer.

DO NOT use furniture polish or silicone spray that is not specifically made for shuffleboards.

3. For ULTIMATE SPEED apply a light coat of Olhausen Games Silicone Spray to keep powder on the playfield and reduce tracing. After applying Silicone Spray, wait a few minutes before applying Olhausen Games Speed Powder. You are now ready to play shuffleboard.

*Accu-Lock*®